



Compressed Air & Gas Treatment On-Site Gas Generation Process Cooling

D' NDL 010 LDP to 050 LDP – Canada* Parts Guide

*IMPORTANT NOTE: For NDL 010 LDP to NDL 050 LDP in Canada with serial number under 21-K1455.01, please use the NDL 010 LDP to NDL 050 LDP United States version parts guide.



LOW DEW POINT HEATLESS MODULAR AIR DRYERS CANADIAN VERSION

D¹

NDL 010 LDP to NDL 050 LDP

Service Intervals For D¹ NDL LDP

Canadian CRN Version*

Daily Checks

- Check the unit for any signs of external damage.
- If the red service indicator is active, the unit must be serviced to ensure continued operation.
- Remove any loose dust or dirt from the unit, clean all surfaces that appear to have attracted unwanted contaminants.
- Ensure the unit is operating within the specification
- Always check all connections for any leaks.
- Ensure all loose parts are removed or secured to the unit before operation.

Service Intervals

Service	Time Period (Months)			
	12	24	36	48
A	✓	✓	✓	✓
B		✓		✓
C				✓
E*	✓	✓	✓	✓

*(ES models only)

Service A – Every 1 year (12 months)

- Replace external coalescing pre-filters elements
- (optional if fitted) Replace any external particulate or activated carbon filter element
- Replace any external filters internal float drain or clean external time drains strainers
- Replace external exhaust silencer/muffler element
- Applicable to all models

Service B – Every 2 year (24 months)

- Replace desiccant cartridges
- Replace top manifold gasket seals
- Replace internal inlet and outlet ball valve & seals
- Applicable to all models

Service C – Every 4 year (48 months)

- Replace exhaust valves
- Applicable to all models

Service E – Every 1 year (12 months)

- Replace dew point sensor
- Applicable to ES models only

***IMPORTANT NOTE:** For NDL 010 LDP to NDL 050 LDP in Canada with serial number under 21-K1455.01, please use the NDL 010 LDP to NDL 050 LDP United States parts guide.





Service 'A' Details

Replace external coalescing pre-filters element

External coalescing pre-filters may vary from one installation to another. Consult filter housings name plate for model of filter housing and of replacement filter elements. For more information on filters, consult the NF or GFN filter parts guide.

Replace any external particulate or activated carbon filter element (Optional if fitted)

External particulate and activated carbon filter may vary from one installation to another. Consult filter housing name plate for model of filter housing and of replacement filter element. For more information on filters, consult the NF or GFN filter parts guide.

Replace any external filter internal float drains if equipped

NF 0008 to 0050 filter housing	NDK 0050
--------------------------------	----------

GF 0006 to 0050 filter housing	GFDK 0050
--------------------------------	-----------

Replace external exhaust silencer/muffler element

Exhaust silencer kit for NDL 010 LDP to NDL 050 LDP	MMK 130
---	---------

Service 'B' Details

Replace desiccant cartridges, replace top manifold gasket seals & internal inlet and outlet ball valve & seals

All D¹ NDL LDP service kits includes:

- (2) desiccant cartridges with outlet filtration
- (2) valve balls
- (6) o-rings
- (2) gasket seals

Kit for NDL 010 LDP	NDK 010
Kit for NDL 020 LDP	NDK 020
Kit for NDL 030 LDP	NDK 030
Kit for NDL 040 LDP	NDK 040
Kit for NDL 050 LDP	NDK 050 LDP

Service 'C' Details

Replace exhaust valves

Complete valve rebuild kit includes:

- (2) valves with diaphragm
- (2) 24 VDC coils

Kit for NDL 010 to 050	NVK 050-024
------------------------	-------------

Service 'E' Details (only ES fitted with ES option)

Replace dew point sensor

ES option service kit	NSK 130
-----------------------	---------



LOW DEW POINT HEATLESS MODULAR AIR DRYERS CANADIAN VERSION

D¹

NDL 010 LDP to NDL 050 LDP

Kit Details and Individual Parts

Exhaust Silencer Kits

MMK 130



Replacement Dew Point Sensor Kit

NSK 130



Replacement Desiccant Kit

NDK 010 LDP, for NDL 010

NDK 020 LDP, for NDL 020

NDK 030 LDP, for NDL 030

NDK 040 LDP, for NDL 040

NDK 050 LDP, for NDL 050 LDP



Replacement Solenoid Coils 24v DC

RCK-024



Replacement Exhaust Valve Kit

NVK 050-024





Headquarters

United States

Charlotte, North Carolina

Phone: +1 704 897 2182

Email: support@airandgassolutions.com

United States

Maryville, Tennessee

Phone: +1 704 897 2182

Email: support@airandgassolutions.com

Canada

St. Catharines, Ontario,

Phone: +1 905 684 6266

Email: canadasupport@airandgassolutions.com

United Kingdom

Gateshead, United Kingdom

Phone: +44 (0) 191 497 7700

Email: sales_uk@nano-purification.com

Germany

Maastrichter Str. 12, 41812 Erkelenz, Germany

Phone: +49 (0) 2431 9550 600

Email: sales_de@nano-purification.com

Singapore

Singapore,

Phone: +65 6748 7988

Email: sales.asia@nano-purification.com



Experience. Customer. Service.

www.nano-purification.com