



# Compressed Air & Gas Treatment On-Site Gas Generation Process Cooling

A background image consisting of a 3D wireframe grid of cubes and rectangular prisms, rendered in a glowing blue color. The perspective is from a low angle, looking up at the structures. Some of the cubes have a circular logo with a stylized 'n' inside, similar to the nano logo.

**GF 0006 WS to 1500 WS**  
Parts Guide



# WATER SEPARATOR HOUSING



GF 0006 WS to GF 1500 WS

## Service Intervals

WS
<p>Yearly:</p> <ul style="list-style-type: none"> <li>• Replace filter housing o-ring</li> <li>• Replace filter drain</li> </ul>

## Spares & Accessories

Internal Condensate Drains		
Automatic float drain with manual override	GF 0006 WS to GF 0050 WS	GFDK 0050
Automatic float drain with manual override	GF 0070 WS to GF 1500 WS	GFDK 1500

Manual Drains		
Manual drain	GF 0006 WS to GF 0050 WS	GFMDK 0050
Manual drain	GF 0070 WS to GF 1500 WS	GFMDK 1500

Drain Adapters For Bowls		
¼" NPT drain adapter	GF0006 WS to GF 0050 WS	GFAK 0050
½" NPT drain adapter	GF0070 WS to GF 1500 WS	GFAK 1500

Housing O-Ring Seal		
GF 0006 WS to 0015 WS		GFSK 0015
GF 0025 WS to 0050 WS		GFSK 0050
GF 0070 WS to 0175 WS		GFSK 0175
GF 0280 WS to 0325 WS		GFSK 0325
GF 0700 WS		GFSK 0700
GF 0850 WS to 1500 WS		GFSK 1500

Wall Mounting Kits	Wall Mounting Kit
GF 0006 WS to 0015 WS	
GF 0025 WS to 0050 WS	GFMK 0050
GF 0070 WS to 0175 WS	GFMK 0175
GF 0280 WS to 0325 WS	GFMK 0325
GF 0700 WS	GFMK 0700
GF 0850 WS to 1500 WS	GFMK 1500



## WATER SEPARATOR HOUSING

GF 0006 WS to GF 1500 WS



### Kits Details and Individual Parts

#### Internal Condensate Drains

GFDK 0050, for GF 0006 WS to GF 0050 WS



GFDK 1500, for GF 0070 WS to GF 1500 WS



#### Manual Drains

GFMDK 0050, for GF 0006 WS to GF 0050 WS



GFMDK 1500, for GF 0070 WS to GF 1500 WS



#### Drain Adapters For Bowls

GFAK 0050, for GF0006 WS to 0050 WS



GFAK 1500, for GF0070 WS to 1500 WS

Image not available at this time.

#### Housing O'ring Seal

GFSK 0015, for GF 0006 WS to 0015 WS

GFSK 0050, for GF 0025 WS to 0050 WS

GFSK 0175, for GF 0070 WS to 0175 WS

GFSK 0325, for GF 0280 WS to 0325 WS

GFSK 0700, for GF 0400 WS to 0700 WS

GFSK 1500, for GF 1250 WS to 1500 WS





## WATER SEPARATOR HOUSING

GF 0006 WS to GF 1500 WS

F1.1

### Wall Mounting Kits

GFMK 0015, for GF 0006 to 0015

GFMK 0050, for GF 0025 to 0050

GFMK 0175, for GF 0070 to 0175

GFMK 0325, for NF 0280 to 0325

GFMK 0700, for GF 0700

GFMK 1500, for GF 0850 to 1500





---

## Headquarters

### United States

Charlotte, North Carolina

Phone: +1 704 897 2182

Email: [support@airandgassolutions.com](mailto:support@airandgassolutions.com)

### United States

Maryville, Tennessee

Phone: +1 704 897 2182

Email: [support@airandgassolutions.com](mailto:support@airandgassolutions.com)

### Canada

St. Catharines, Ontario,

Phone: +1 905 684 6266

Email: [canadasupport@airandgassolutions.com](mailto:canadasupport@airandgassolutions.com)

### United Kingdom

Gateshead, United Kingdom

Phone: +44 (0) 191 497 7700

Email: [sales\\_uk@nano-purification.com](mailto:sales_uk@nano-purification.com)

### Germany

Maastrichter Str. 12, 41812 Erkelenz, Germany

Phone: +49 (0) 2431 9550 600

Email: [sales\\_de@nano-purification.com](mailto:sales_de@nano-purification.com)

### Singapore

Singapore,

Phone: +65 6748 7988

Email: [sales.asia@nano-purification.com](mailto:sales.asia@nano-purification.com)

**nano**

Experience. Customer. Service.

[www.nano-purification.com](http://www.nano-purification.com)