Compressed Air & Gas Treatment
On-Site Gas Generation
Process Cooling

GFN/GF 0006 to 1500
Parts Guide

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

F1.1

Service Intervals

M1, M01 Filter Elements	AC Filter Elements
Yearly: • Replace filter element • Replace filter housing o-ring • Replace filter drain	1000 hours: • Replace filter element • Replace filter housing o-ring

Kits

Filter model	M1	M01	AC
GFN0006(GRADE) or GF0006(GRADE)	GE0015M1	GE0015M01	GE0015AC
GFN0015(GRADE) or GF0015(GRADE)	GE0015M1	GE0015M01	GE0015AC
GFN0025(GRADE) or GF0025(GRADE)	GE0032M1	GE0032M01	GE0032AC
GFN0032(GRADE) or GF0032(GRADE)	GE0032M1	GE0032M01	GE0032AC
GFN0050(GRADE) or GF0050(GRADE)	GE0050M1	GE0050M01	GE0050AC
GFN0070(GRADE) or GF0070(GRADE)	GE0105M1	GE0105M01	GE0105AC
GFN0085(GRADE) or GF0085(GRADE)	GE0105M1	GE0105M01	GE0105AC
GFN0105(GRADE) or GF0105(GRADE)	GE0105M1	GE0105M01	GE0105AC
GFN0125(GRADE) or GF0125(GRADE)	GE0175M1	GE0175M01	GE0175AC
GFN0175(GRADE) or GF0175(GRADE)	GE0175M1	GE0175M01	GE0175AC
GFN0280(GRADE) or GF0280(GRADE)	GE0325M1	GE0325M01	GE0325AC
GFN0325(GRADE) or GF0325(GRADE)	GE0325M1	GE0325M01	GE0325AC
GFN0450(GRADE) or GF0450(GRADE)	GE0450M1	GE0450M01	GE0450AC
GFN0700(GRADE) or GF0700(GRADE)	GE0700M1	GE0700M01	GE0700AC
GFN0850(GRADE) or GF0850(GRADE)	GE0900M1	GE0900M01	GE0900AC
GFN0900(GRADE) or GF0900(GRADE)	GE0900M1	GE0900M01	GE0900AC
GFN1250(GRADE) or GF1250(GRADE)	GE1250M1	GE1250M01	GE1250AC
GFN1500(GRADE) or GF1500(GRADE)	GE1500M1	GE1500M01	GE1500AC

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

Spares & Accessories

Internal Condesate Drains		
Automatic float drain with manual override	GFN (GF) 0006 to GFN (GF) 0050	GFDK 0050
Automatic float drain with manual override	GFN (GF) 0070 to GFN (GF) 1500	GFDK 1500

Manual Drains		
Manual drain	GFN (GF) 0006 to GFN (GF) 0050	GFMDK 0050
Manual drain	GFN (GF) 0070 to GFN (GF) 1500	GFMDK 1500

NPT Adapters For Bottom Filter Bowls		
NPT adapters ¼" NPT(F)	GFN (GF) 0006 to GFN (GF) 0050	GFAK 0050
NPT adapters ½" NPT(F)	GFN (GF) 0070 to GFN (GF) 1500	GFAK 1500

Differnetial Pressure Indicators & Gauges		
Pop up differential pressure indicators	GFN (GF) 0025 to GFN (GF) 0050	GFDP 0050
Differential pressure gauge	GFN (GF) 0070 to GFN (GF) 1500	GFDP 1500

NC differential volt free contact*	GFN (GF) 0025 to GFN (GF) 1500	GFPE NC
NO differential volt free contact*	GFN (GF) 0025 to GFN (GF) 1500	GFPE NO

*requires unit to have differential pressure gauge installed

Housing O-Ring Seal	
GFN (GF) 0006 to 0015	GFSK 0015
GFN (GF) 0025 to 0050	GFSK 0050
GFN (GF) 0070 to 0175	GFSK 0175
GFN (GF) 0280 to 0325	GFSK 0325
GFN (GF) 0450 to 0700	GFSK 0700
GFN (GF) 0850 to 1500	GFSK 1500

Wall Mounting Kits	
GFN (GF) 0006 to 0015	GFMK 0015
GFN (GF) 0025 to 0050	GFMK 0050
GFN (GF) 0070 to 0175	GFMK 0175
GFN (GF) 0280 to 0325	GFMK 0325
GFN (GF) 0400 to 0700	GFMK 0700
GFN (GF) 0850 to 1500	GFMK 1500

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

Connecting Kits	
2-Housings	
GFN (GF) 0006 to 0015	GFCK-2 0015
GFN (GF) 0025 to 0050	GFCK-2 0050
GFN (GF)0070 to 0175	GFCK-2 0175
GFN (GF) 0280 to 0325	GFCK-2 0325
GFN (GF) 0400 to 0700	GFCK-2 0700
GFN (GF) 0850 to 1500	GFCK-2 1500
3-Housings	
GFN (GF) 0006 to 0015	GFCK-3 0015
GFN (GF) 0025 to 0050	GFCK-3 0050
GFN (GF) 0070 to 0175	GFCK-3 0175
GFN (GF) 0280 to 0325	GFCK-3 0325
GFN (GF) 0400 to 0700	GFCK-3 0700
GFN (GF) 0850 to 1500	GFCK-3 1500
4-Housings	
GFN (GF) 0006 to 0015	GFCK-4 0015
GFN (GF) 0025 to 0050	GFCK-4 0050
GFN (GF) 0070 to 0175	GFCK-4 0175
GFN (GF) 0280 to 0325	GFCK-4 0325
GFN (GF) 0400 to 0700	GFCK-4 0700
GFN (GF) 0850 to 1500	GFCK-4 1500

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

Kits Details and Individual Parts

Filter Elements

M1

M01

AC

Internal Condensate Drains

GFDK 0050, for GFN (GF) 0006 to GFN (GF) 0050

GFDK 1500, for GFN (GF) 0070 to GFN (GF) 1500

Manual Drains

GFMDK 0050, for GFN (GF) 0006 to GFN (GF) 0050

GFMDK 1500, for GFN (GF) 0070 to GFN (GF) 1500

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

NPT Adapters for Bottom Filter Bowls

GFAK 0050, for GFN (GF) 0006 to GFN (GF) 0050

GFAK 1500, for GFN (GF) 0070 to GFN (GF) 1500

Image not available at this time.

Differential Pressure Indicators and Accessories

GFDP 0050, for GFN (GF) 0025 to GFN (GF) 0050

GFDP 1500, for GFN (GF) 0070 to GFN (GF) 1500

GFPE NC*, for GFN (GF) 0025 to GFN (GF) 1500

Image not available at this time.

GFPE NO*, for GFN (GF) 0025 to GFN (GF) 1500

Image not available at this time.

**Requires unit to have differential pressure gauge installed*

Housing O'ring Seal

GFSK 0015, for GFN (GF) 0006 to 0015

GFSK 0050, for GFN (GF) 0025 to 0050

GFSK 0175, for GFN (GF) 0070 to 0175

GFSK 0325, for GFN (GF) 0280 to 0325

GFSK 0700, for GFN (GF) 0400 to 0700

GFSK 1500, for GFN (GF) 0850 to 1500

PERFORMANCE VALIDATED FILTERS

GFN 0006 to GFN 1500 and GF 0006 to GF 1500

Wall Mounting Kits
GFMK 0015, for GFN (GF) 0006 to 0015
GFMK 0050, for GFN (GF) 0025 to 0050
GFMK 0175, for GFN (GF) 0070 to 0175
GFMK 0325, for GFN (GF) 0280 to 0325
GFMK 0700, for GFN (GF) 0400 to 0700
GFMK 1500, for GFN (GF) 0850 to 1500

Connecting Kits, 2-Housings
GFCK-2 0015, for GFN (GF) 0006 to 0015
GFCK-2 0050, for GFN (GF) 0025 to 0050
GFCK-2 0175, for GFN (GF) 0070 to 0175
GFCK-2 0325, for GFN (GF) 0280 to 0325
GFCK-2 0700, for GFN (GF) 0400 to 0700
GFCK-2 1500, for GFN (GF) 0850 to 1500

Connecting Kits, 3-Housings
GFCK-3 0015, for GFN (GF) 0006 to 0015
GFCK-3 0050, for GFN (GF) 0025 to 0050
GFCK-3 0175, for GFN (GF) 0070 to 0175
GFCK-3 0325, for GFN (GF) 0280 to 0325
GFCK-3 0700, for GFN (GF) 0400 to 0700
GFCK-3 1500, for GFN (GF) 0850 to 1500

Connecting Kits, 4-Housings
GFCK-4 0015, for GFN (GF) 0006 to 0015
GFCK-4 0050, for GFN (GF) 0025 to 0050
GFCK-4 0175, for GFN (GF) 0070 to 0175
GFCK-4 0325, for GFN (GF) 0280 to 0325
GFCK-4 0700, for GFN (GF) 0400 to 0700
GFCK-4 1500, for GFN (GF) 0850 to 1500

Headquarters

United States
Charlotte, North Carolina
Phone: +1 704 897 2182
Email: support@airandgassolutions.com

United States
Maryville, Tennessee
Phone: +1 704 897 2182
Email: support@airandgassolutions.com

Canada
St. Catharines, Ontario,
Phone: +1 905 684 6266
Email: canadasupport@airandgassolutions.com

United Kingdom
Gateshead, United Kingdom
Phone: +44 (0) 191 497 7700
Email: sales_uk@nano-purification.com

Germany
Maastrichter Str. 12, 41812 Erkelenz, Germany
Phone: +49 (0) 2431 9550 600
Email: sales_de@nano-purification.com

Singapore
Singapore,
Phone: +65 6748 7988
Email: sales.asia@nano-purification.com

Experience. Customer. Service.

www.nano-purification.com

Technical specifications subject to change without notice.
Publication Reference: F1.1-GFN-US-EN-Version-000
©2025 Air & Gas Solutions LLC