

# installation manual

## SEP 60 ST single use condensate cleaner



1


Before starting assembly, please read the following:

SEP 60 ST is a single-use product. It should be replaced as directed to ensure its vital environmental and legally protective functions are performed correctly.

SEP 60 ST has been designed to clean condensate from a compressor system of up to 60 cfm (1.7 m<sup>3</sup>/min) to better than 10 ppm oil-in-water; suitable for discharge to a sanitary sewer. **NOTE: This is generally well below the accepted level, but it is the users responsibility to ensure compliance with local regulations.**

### Top Inlet Port


The unit comes shipped with a 1/4" inlet port as standard.



Other size inlet ports are available upon request. Contact nano for additional information.

## installation

2



Fix the wall plate vertically on a suitable wall or the compressor cabinet. Isolate the compressor and look out for cables and pipes when drilling.

3



Slide the SEP 60 ST on to the plate, with the venting flutes at the top.


4



Connect all drain points, insert tube into push fitting in the inlet (top).

- 1/4" tube for imperial

5



Connect tube into outlet fitting and feed to drain (side). Ensure a steady fall from outlet point to drain with no kinks or tight bends.

- 3/8" tube for imperial

6

**IMPORTANT - Always use an automatic drain.** Set timers to short open periods of one second or less. **NEVER** use manual drains which could flood the separator, forcing partially treated or untreated condensate to be discharged.

## replacement

<p><b>1</b></p>  <p>Ensure the condensate drain(s) are switched off.</p> <p>Disconnect inlet and outlet tubes from their quick fittings.</p>	<p><b>2</b></p>  <p>Lift SEP 60 ST from the wall plate.</p>	<p><b>3</b></p>  <p>Push fit the retained disposal lid (that came with your kit) onto the top of the unit.</p>	<p><b>4</b></p>  <p>Insert transit plug into outlet (this comes with each kit).</p> <p>Please note this is designed to create a tight seal and cannot be removed once inserted.</p>	<p><b>5</b></p>  <p>Unit is now sealed for transport to a licensed waste disposal site.</p> <p>Refit the new SEP 60 ST to the existing wall plate and connect as before.</p>
--	--	---	---	---

## the SEPURA™ range condensate separators to suit your requirements



**Inquire about our replacement filter kits for all major OEM brands.**  
For more information, please visit our website at [www.n-psi.com](http://www.n-psi.com) or call 704.897.2182