



Compressed Air & Gas Treatment On-Site Gas Generation Process Cooling

The background of the lower half of the page is a dark blue field filled with a complex, three-dimensional wireframe structure. This structure consists of numerous overlapping cubes and rectangular frames, creating a sense of depth and geometric complexity. Scattered throughout this wireframe are several instances of the nano logo, some appearing as glowing points of light and others as larger, more prominent symbols. The overall effect is a high-tech, futuristic aesthetic.

B' NBM 030 to 960
Parts Guide



BREATHING AIR PURIFICATION MODULE

NBM 030 to NBM 960

B¹

Service Intervals For B¹ NBM

Daily Checks

- Check the unit for any signs of external damage.
- Remove any loose dust or dirt from the unit, clean all surfaces that appear to have attracted unwanted contaminants.
- Ensure the unit is operating within the specification
- Always check all connections for any leaks.
- Ensure all loose parts are removed or secured to the unit before operation.

Service Intervals

Service	Time Period (Months)			
	12	24	36	48
A	✓	✓	✓	✓

Service A – Every 1 year (12 months)

- Replace mix bed adsorbent cartridges
- Replace top manifold gasket seals
- Applicable to all models

Service ‘A’ Details

Replace mix bed adsorbent cartridges, replace top manifold gasket seals

All B¹ NBM service kits includes:

- Mix bed adsorbent cartridges with outlet filtration
- Seals

Replacement adsorbent for NBM 030	NBM SK 030
Replacement adsorbent for NBM 120	NBM SK 120
Replacement adsorbent for NBM 240	NBM SK 240
Replacement adsorbent for NBM 480	NBM SK 480
Replacement adsorbent for NBM 720	NBM SK 720
Replacement adsorbent for NBM 960	NBM SK 960

Kit Details and Individual Parts

Replacement adsorbent kit

NBM SK 030

NBM SK 120

NBM SK 240

NBM SK 480

NBM SK 720

NBM SK 960





Headquarters

United States

Charlotte, North Carolina

Phone: +1 704 897 2182

Email: support@airandgassolutions.com

United States

Maryville, Tennessee

Phone: +1 704 897 2182

Email: support@airandgassolutions.com

Canada

St. Catharines, Ontario,

Phone: +1 905 684 6266

Email: canadasupport@airandgassolutions.com

United Kingdom

Gateshead, United Kingdom

Phone: +44 (0) 191 497 7700

Email: sales_uk@nano-purification.com

Germany

Maastrichter Str. 12, 41812 Erkelenz, Germany

Phone: +49 (0) 2431 9550 600

Email: sales_de@nano-purification.com

Singapore

Singapore,

Phone: +65 6748 7988

Email: sales.asia@nano-purification.com

nano

Experience. Customer. Service.

www.nano-purification.com