

# **User guide** D3 pneumatic heatless desiccant dryer

revision: 2022-312 document: 17-100-0692 © 2022 Air & Gas Solutions LLC www.n-psi.co.uk

# about us

#### Experience.

Our team is comprised of and supported by individuals spanning all disciplines from research & development, engineering & manufacturing, marketing & sales and service & support. Our backgrounds are in air and gas purification and our experience in this field spans a wide range of industries. We combine this knowledge and experience to ensure our products and services are designed and provided to meet the objectives and expectations of you - our Customer.

#### Customer.

We recognise that our Customers are not only our valuable distribution partners who sell and support our products or the machine builders who depend on them as protection for their equipment. They are the contractors who install them, the manufacturers who use them in their processes and the service people who maintain them. At nano we have developed our products, packaging and support materials to ensure they exceed all of our Customers' expectations.

#### Service.

At nano we recognise that world-class customer service is the most important component to any successful business. Your business needs to exceed your customers' expectations to stand out from your competitors and our service must positively impact your business so you can be successful in doing so. Our commitment is simple... we will stand behind our products and ensure that our customer service is unrivaled in the industry.

## Experience. Customer. Service.



section	description	page			
1	manufacturers detials and support	4			
1.1	general information				
1.2	document introduction				
1.3	warranty guidelines	5			
1.4	general safety				
1.5	intended use of the product				
2	technical specification	0			
2.1	flow rates	6			
2.2	product dimensions	7			
3	product overview	8			
3.1	typical system layout	9			
3.2	site location				
4	maintenance				
4.1					
4.2	daily checks				
4.3	service schendule and breakdown	11			
5	trouble shooting	12			
6	process and instrumentation diagram	13			
	notes	14-15			



# D3

## pneumatic heatless desiccant dryer

#### 1. manufacturers detials and support

#### nano-purification solutions ltd. (Manufacturer)

address:	Dukesway
	Team Valley Trading Estate Gateshead
	NE11 OPZ
	United Kingdom
telephone:	+44 (0) 191 497 7700
internet:	www.n-psi.co.uk
email	sales@n-psi.co.uk

#### germany - nano-purification solutions GmbH

address:	Maastrichter Straße 12
	D-41812
	Erkelenz
	Germany
telephone:	+49 2431 9550 600
internet:	www.n-psi.de
email	sales@n-psi.de

#### usa - nano-purification solutions

address:	5509 David Cox Road
	Charlotte,
	NC 28269
	USA
telephone:	+1 (704) 897-2182
internet:	www.n-psi.com
email:	support@n-psi.com

#### canada - nano-purification solutions

address:	7 Petrie Street
	St. Catharines,
	Ontario
	L2P 3J6
	Canada
telephone:	+1 (905) 684-626
internet:	www.n-psi.com
email:	support@n-psi.com

#### singapore - nano purification solutions

address:	singapore
	singapore
telephone:	+65 6748 7988
internet:	www.n-psi.com
email:	sales@biremegroup.com



**WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and/or birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

**CAUTIONS**: indicate any situation or operation that may result in potential damage to the product, injury to the user,

NOTES: highlight important sections of

information where particular care and

or render the product unsafe.

attention should be paid.

annotations

D3

#### 1.1 general information

This manual is copyrighted, all rights reserved. It may not, in whole or in part, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine readable form without prior consent in writing from Air & Gas Solutions LLC. It may not be distributed through the internet or computer bulletin board systems without prior consent from Air & Gas Solutions LLC.

#### 1.2 document introduction

This manual provides factory prescribed installation and maintenance procedures for the pneumatic heatless desiccant dryer. The procedures illustrated in this document are only to be performed by authorized personnel. For further information regarding the procedures outlined in this document contact the manufacturer before proceeding. Be sure to read this document carefully before attempting to install or operate the pneumatic heatless desiccant dryer. This document should be permanently available at the pneumatic heatless desiccant dryer installation site.

#### 1.3 warranty guidelines

All products are supplied with a 2 year manufacturer's warranty from the date of purchase when installed and maintained in accordance with the manufacturers guidelines. Only genuine service parts should be used and no modifications made.

#### 1.4 general safety

No modifications must be made to the product. Any modifications may reduce the operational safety of the product and invalidate the manufacturer's warranty. This could potentially result in damage to the product and serious personal injury.

For your own safety, when carrying out work on this product, all relevant national safety regulations must be complied with relating to pressurized and electrical systems.

Only authorized, competent and trained personnel are permitted to work on this product. This user guide is intended solely for such personnel and is to be used only as a reference; it should not be used to replace conventional training.

#### 1.5 intended use of the product

The pneumatic heatless desiccant dryer is exclusively intended for the treatment of compressed air, which is free from bulk water, oil and solid matter constituents.

The product should be located within a building and protected from extreme conditions and weather. The pneumatic heatless desiccant dryer must be operated only in accordance with the data on the rating plate. Any operations that do not comply with those stated on the product rating label will render the warranty void



#### 2. technical specification

specifications	standard	options
maximum water content (ISO class)	class 2 -40°C (-40°F) pdp	class 1: -70°C (-94°F) pdp
minimum operating pressure	4 barg (58 psig)	-
maximum operating pressure	10 barg (145 232psig)	-
recommended operating temp range	10 to 30°C (35 to 95°F)	-
design operating temperature range	1.5 to 50°C (35 to 122°F)	-

ISO Class 2 at recommended max rated flow at 7 barg and 25°C inlet; see correction factors

#### 2.1 flow rates

 $\bigcirc$ 

model	inlet flo	w rate	conn	connection	
model	Nm³/hr	scfm	inlet	outlet	
NDM - 2110-PNU	360	212			
NDM - 2120-PNU	469	276	2"	2″	
NDM - 2130-PNU	680	400	BSPP or NPT	BSPP or NPT	
NDM - 3130-PNU	951	560			
NDM - 4130-PNU	1274	750			
NDM - 6120-PNU	1407	828	2 1/2" BSPP or NPT	2 1/2" BSPP or NPT	
NDM - 6130-PNU	1886	1110			

### 2.2 product dimensions



			dim	nension				
model	Α		В		С		weight	
	mm	inches	mm	inches	mm	inches	kg	lbs
NDM - 2110-PNU	1249	49.1			659	25.6	123	348
NDM - 2120-PNU	1499	59.0			659	25.6	134	394
NDM - 2130-PNU	1849	72.8			659	25.6	159	478
NDM - 3130-PNU	1849	72.8	400	15.7	827	32.2	208	652
NDM - 4130-PNU	1849	72.8			991	38.8	261	833
NDM - 6120-PNU	1499	59.2			1327	52.1	304	963
NDM - 6130	1849	72.8			1327	52.1	367	1197



3. product overview



number	description					
1	compressed air inlet					
2	compressed air outlet					
3	pneumatic control box					
4	exhaust silencer					
5	dryer column					



#### 3.1 typical system layout



IMPORTANT: It is essential that the system into which the unit is installed is fitted with a pressure limiting/ relief device. This device should be installed between the compressor and the unit.



#### 3.2 site location

When selecting an installation site for the unit, ensure the following conditions are met:

- Installation site should be located indoors on a flat surface protected from the weather and other harmful conditions.
- The ambient temperature must not drop below 1.5°C (34.7°F) or exceed 50°C (122°F).
- The installation site should be level and able to support the weight of the product.
- Ensure sufficient space around the product, to allow access for operation and maintenance.
- Take into account the noise generated by the unit exhausting while in use when considering location.



#### 4. maintenance



## Maintenance operations should only be conducted once the system has been shut down and is fully depressurized. All operations should be carried out by authorized and suitably trained personnel.

- Isolate the unit from the compressed air supply ensuring the system is in a safe condition for maintenance to be carried out.
- All connections must be removed with care, paying particular attention to the areas that become pressurized.
- All seals removed during maintenance operations must be replaced with new seals.
- Only certified and approved replacement parts should be used.

D3

- Do not modify or adjust the control settings.
- Check all connections and sealing faces for cleanliness and secure seating prior to assembly.
- Ensure all components are re-fitted to the product before operation.
- Check all connection and sealing faces for any leakage, if any found resolve and check again.
- Ensure the unit is left operating in a safe working condition after completion of maintenance.

#### 4.1 cleaning

Clean the equipment with a damp cloth only and avoid excessive moisture around any connections. If required a mild detergant can be used. Do not use abrasives/solvents as these may cause damage.

#### 4.2 daily checks

- Check the unit for any signs of external damage.
- If the red service indicator is active, the unit must be serviced to ensure continued operation.
- Remove any loose dust or dirt from the unit, clean all surfaces that appear to have attracted unwanted contaminants.
- Ensure the unit is operating within the specification.
- Always check all connections for any leaks.
- Ensure all loose parts are removed or secured to the unit before operation.



#### 4.3 service schedule and breakdown

Replace inlet valve diaphragms Replace outlet check valve seals

service	year 1 (12 months or or 6,000 hours)	year 2 (24 months or or 12,000 hours)	year 3 (36 months or or 24,000 hours)	year 4 (48 months or or 36,000 hours)	year 5 (60 months or 44,000 hours)	year 6 (72 months or or 53,000 hours)	year 7 (84 months or 61,000 hours)	year 8 (96 months or or 70,000 hours)
А	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$	$\checkmark$
В		$\checkmark$		$\checkmark$		$\checkmark$		$\checkmark$
С				$\checkmark$				$\checkmark$
Se	ervice A -	Every 1 year Replace exte		encer/muffler el	ement			
Se	ervice B -	vice B - Every 2 years (24 months) Replace desiccant Replace top manifold gasket seals						
Se	ervice C -	- Every 4 year (48 months) Replace exhaust valve diaphragms						



When contacting your service provider be sure to provide the part number and serial number of your dryer, this can be found on the rating plate.



D3

# pneumatic heatless desiccant dryer

## 5. trouble shooting

problem	problem caused	solution			
	Insufficient inlet pressure	4 barg (58psig) minimum inlet pressure required to operate, if not, check and restore system pressure			
	Moist or contaminated desiccant	Eliminate the cause of contamination, replace desiccant cartridges (do not re-use)			
Poor dew-point performance	Excessive inlet air temprature	Check against the technical specification			
	Insufficient purge air	Purge incorrectly adjusted, consult the service personnel to adjust the settings (factory pre-set). Consult Service Technician to adjust as per site condition.			
	Exhaust silencer blocked	Replace exhaust silencer/muffler element(s).			
	insufficient inlet pressure	4barg (58psig) minium inlet pressure required to operate, if not, check and restore system pressure			
	outlet flow stops	Check inlet air supply			



#### 6. process and instrumentation diagram





#### notes



#### notes




# Experience. Customer. Service.



tel: +44 (0) 191 497 7700 sales@n-psi.co.uk www.n-psi.co.uk



nano-purification solutions singapore, singapore tel: +65 6748 7988 sales@biremegroup.com www.n-psi.com



nano-purification solutions new bethlehem, pennsylvania tel: +1 724 297 3416 airtak@airtak.com www.airtak.com



nano-purification solutions erkelenz, germany tel: +49 (0) 2431 9550 600 sales@n-psi.de www.n-psi.de



#### nano-purification solutions

st. catharines, ontario, canada tel: +1 905 684 6266 support@n-psi.com www.n-psi.com



nano-purification solutions charlotte, north carolina tel: +1 704 897 2182 support@n-psi.com www.n-psi.com