maintenance kit installation guide SEP 120/360/900 MRK





1

Before starting assembly, please check contents are as follows:

- 1 STERLING filter (removed from plastic bag)
- 2 white pre-filter bag
- metal retaining springs

SEP 120 = 1 x 170 mm

SEP 360 = 1 x 250 mm

SEP 900 = $2 \times 400 \text{ mm}$

service interval kit containing:

- printed card
- self-adhesive timestrip



service indicator - assembly and attachment



- Insert the boss on the reverse of the mount (c) into the predrilled hole in the separator lid.
- Peel backing from timestrip (a) and attach to the plastic card (b) within the dotted lines.
- Flex the card, passing the ends through the slots on the top surface of the mount.

To activate, press firmly on the timestrip label at the point indicated.

After a few minutes, a red line will appear, to indicate 'time in service' up to 12 months.

A replacement card and timestrip will be supplied with each service kit.

general installation notes

- Please ensure a steady fall in the pipe run from the outlet point to the sanitary drain.
- When used in conjunction with timed solenoid drain, set drain "open" duration to minimum setting (1-2 seconds).
- When used in conjunction with motorized ball valve or high capacity drain (ie Drain-all®) a de-pressurization chamber must be installed between drain and Sepura unit.
- Never discharge condensate to a storm drain or to suface water; always connect to a sanitary drain or sewer.
- Remember that it's the user's responsibility to check with the local authority as to the permissible discharges in their area.

testing quality

Replace filters before outlet cloudiness exceeds the ppm limit for your region.

Test outlet quality weekly using kit





















tel: 704.897.2182 email: support@n-psi.com