
# maintenance kit installation guide SEP 1250 MRK







## service indicator - assembly and attachment





Before starting assembly, please check contents are as follows:

- 2 STERLING filters (removed from plastic bag)
- 1 white pre-filter bag
- metal retaining springs
- **SEP 1250** = 2 x 457 mm

### service interval kit containing:

- printed card
- self-adhesive timestrip

## general installation notes

• Please ensure a steady fall in the pipe run from the outlet point to the sanitary drain.

• When used in conjunction with timed solenoid drain, set drain "open" duration to minimum setting (1-2 seconds).

• When used in conjunction with motorized ball valve or high capacity drain (ie Drain-all®) a de-pressurization chamber must be installed between drain and Sepura unit.

• Never discharge condensate to a storm drain or to suface water; always connect to a sanitary drain or sewer.

• Remember that it's the user's responsibility to check with the local authority as to the permissible discharges in their area.

#### testing quality

Replace filters before outlet cloudiness exceeds the ppm limit for your region.

Test outlet quality weekly using kit provided.







body, settling it down gently, and ensuring it is in contact with the side wall.



Insert the second filter (needle-felt bag with black inlet tube) and rest it on top of the retainers.





tel: 704.897.2182 email: support@n-psi.com

www.n-psi.com





Connect the filter tube to the inlet block using the fittings supplied.



Install the securing spring clips at 90 degrees directly in contact with the filter bags to prevent floatation.



Attach the twist off grab tap to the test point. Attach your outlet hose to the nipple above. Fill unit with water and check for leaks.



copyright PURIFICATION SOLUTIONS LLC publication reference n-psi-S1-SEP1250MRK-02-us